# eventlo. oivot

roller/Travel System ussette / Système de déplacement

rriola/Sistema de viaje

| ller   | Up to 50 lbs (22.6 kg)                           |
|--------|--|
|        | Up to 38 in. (96 cm)                             |
| ssette | Jusqu'à 22,6 kg (50 lb)<br>Jusqu'à 96 cm (38 po) |
| iola   | Hasta 22.6 kg (50 lb)<br>Hasta 96 cm (38 pulg)   |



d all instructions before assembly and use of product.

P INSTRUCTIONS FOR FUTURE USE.

les instructions avant l'assemblage et l'utilisation du produit.

NSERVER CES INSTRUCTIONS POUR RÉFÉRENCE ULTÉRIEURE.


las instrucciones antes de armar y usar el producto.


ARDE ESTAS INSTRUCCIONES PARA REFERENCIA FUTURA.

#### TABLE OF CONTENTS

| Warnings   |
|--|
| Important Information  |
| mportant information   |
| dentification of Parts   |
| Choosing Mode of Use   |
| Assembling Your Stroller   |
| Using Your Stroller  |
| Using your Stroller with the Recommended Infant Car Seats on your Stroller Frame |
| Using your Stroller with the Recommended Infant Car Seats in your Toddler Seat   |
| Care and Maintenance   |
| Limited Warranty   |

#### **FEATURES**







- 1. Canopy
- 2. Parent's Handle
- 3. Fold Latch
- 4. Cupholder
- **5.** Toddler Seat Release Button
- 6. Swivel Wheel

- 7. Footrest
- 8. Buckle
- 9. Harness Covers
- 10. Bumper Bar
- 11. Child Tray
- 12. Shoulder Straps
- **13.** Multi-Position Recline Strap
- 14. Side Frame Lock
- 15. Storage Basket
- 16. Brakes

## ParentLink.

answers. advice. affirmation.™

- www.evenflo.com USA: 1-800-233-5921 8 AM 5 PM E.T.
  - Canada: 1-937-773-3971 México: 01-800-706-12-00

## **AWARNING**

## READ AND FOLLOW ALL WARNINGS AND INSTRUCTIONS! FAILURE TO DO SO COULD RESULT IN SERIOUS INJURY OR DEATH!

Only use Evenflo SafeMax™ and LiteMax™ infant car seats with this stroller.

Other infant car seats or carriers are not designed to fit the stroller frame and if used with this stroller may result in serious injury to your child.

**NEVER** leave child unattended. **ALWAYS** keep child in view while in the stroller.

Adult assembly required. Take care when unpacking and assembling; contains small parts and some items with sharp edges.

To prevent a possible choking hazard, remove and discard packing material before using this product.

Avoid serious injury from falling or sliding out. **ALWAYS** use waist restraint.

**DO NOT** carry or roll stroller on stairs or escalators with child in it.

**DO NOT** hang items on handle bar or place them on the canopy as they can tip stroller over and injure child.

Be sure stroller is fully assembled and locked in unfolded position before using.

**ALWAYS** exercise care when going over curbs or steps, and never use stroller for anything other than transporting your child. Push stroller at a normal walking pace only; faster strolling can cause a loss of control and injury to the child.

**DO NOT** place hot liquids in cup holder. Spills can burn you or your child.

To avoid serious injury from child falling out of stroller, **DO NOT** raise or recline seat with child in stroller.

**DO NOT** use stroller if any parts are missing or broken.

**DO NOT** allow child to climb on, into, out of, or around stroller.

**DO NOT** allow child to stand on the footrest. Stroller may tip over and injure child.

**DO NOT** carry additional children, goods, or accessories in or on this stroller except as advised in these instructions. The stroller is intended for use with one child occupant and to accommodate only the additional weights in storage as listed in these instructions.

Care must be taken when folding or unfolding stroller to prevent finger injury to you or your child in hinge areas.

Make sure child is not in the seat or near the stroller when folding or unfolding.

**NEVER** leave stroller on a hill or incline, even with brakes set. Stroller may tip, injuring the child.

To avoid accidental rolling, **ALWAYS** set brakes when stroller is not being pushed.

#### **AVOID STRANGULATION:**

- **DO NOT** suspend strings or toys from the canopy.

- **DO NOT** place stroller anywhere near cords from window blinds, draperies, phone, etc.

- **DO NOT** place items with a string around your child's neck such as hood strings or pacifier cords.

- If not properly secured, the child may slip into leg openings and strangle.

When making adjustments to the stroller, **ALWAYS** ensure that all parts of the child's body are clear of any moving parts of the stroller.

The canopy is not intended to provide UV protection.

Sharp or heavy objects placed in pockets may cause damage to the stroller, or injury to the child.

To ensure safety for your baby, please refer to the manufacturer's instructions for the use of your recommended infant car seats and keep all instructions available for reference.

**DO NOT** lift stroller by using the infant car seat handle when installed on stroller.

If unable to securely attach the infant car seat to this stroller, remove the car seat and contact **Evenflo ParentLink** 

at 1-800-233-5921 (USA), 1-937-773-3971 (Canada), or 01-800-706-12-00 (Mexico).

To avoid serious injury, make sure the infant car seat is securely snapped onto the car seat mounts.

Some **Evenflo SafeMax<sup>TM</sup> and LiteMax<sup>TM</sup>** infant car seats have a blanket/boot option that must be removed for proper attachment to the stroller.

To avoid stroller instability and tip-overs, **DO NOT** load cup holder with over 1 lb (0.45 kg), the main cargo basket with over 10 lbs (4.5 kg).

**Never** use the toddler seat without the canopy attached.

**Never** lift or carry the toddler seat by the armbar.

**Never** use the stroller frame without the toddler seat or car seat attached.

**Never** use toddler seat in a motor vehicle or use it as a booster seat.

**To avoid falls,** never remove toddler seat from the stroller with child in it.

**To avoid falls**, always make sure the toddler seat or car seat is securely attached into the seat mounts on both sides the stroller before placing child in the seat.

**When stroller is in carriage mode**, it is intended for a child up to 6 months of age.

**Never** use seat in a reclined carriage position unless the straps under the seat are unbuckled and the seat is set up in reclined carriage mode as per the instructions (page 13-14).

**Never** use the recline handle (pg 12 - Step 5) to recline seat when installing the infant car seat into the toddler seat.

#### IMPORTANT INFORMATION

Child Requirements - When stroller is in carriage mode, it is intended for a child up to 6 months of age. Only use the stroller in the upright position with a child who is capable of sitting upright unassisted.

Maximum weight: 50 lbs (22.6 kg) Maximum height: 38 inches (96 cm)

IMPORTANT: Read instructions carefully before use. Save these instructions for future reference. It is very important to assemble the stroller according to these instructions. If you are missing parts, do not use stroller and call **Evenflo ParentLink at** 1-800-233-5921 (U.S.A.), 1-937-773-3971 (Canada), or 01-800-706-12-00 (Mexico) to order replacement parts. **Registration Information** 

Please register this product so we can reach you if there is a safety alert or recall. We will not sell, rent, or share your personal information. To register your product, please complete and mail the card that came with it or visit our online registration at www.evenflo.com/registerproduct.

For future reference, record the Model Number and Date of Manufacture below. You can find this information on one of the rear stroller legs.

Date of Manufacture: \_ Model Number: \_

#### **IDENTIFICATION OF PARTS**




(2) Front Wheel Assembly



(2) Rear Wheel



Bumper Bar/Child's Tray



Frame



Cupholder



Removable cover Only on certain models

## YOUR STROLLER SEAT CAN BE USED IN TWO DIFFERENT MODES. TODDLER SEAT MODE OR CARRIAGE MODE.

Your stroller seat is shipped in carriage mode with the buckles unfastened under the footrest. You will need to follow the instructions completely to make sure you set up your stroller in your preferred mode of use.


After the frame and the wheels have been assembled, you can choose to set the stroller up in **Carriage Mode** or **Toddler Seat Mode**. Follow instructions on pages 6 - 15.

#### **Carriage Mode**



#### **Toddler Seat Mode**







Care must be taken when folding or unfolding stroller to prevent finger injury in hinge areas.


To protect flooring, place a protective covering (cardboard, towel, small rug or blanket) beneath the stroller during assembly.

Unlatch side frame lock **(a)**. Continue holding the lock open while unfolding the stroller.










Turn the stroller so the front of the stroller is facing upwards, as shown.

To attach front wheels, line up the metal pin with the groove in the front wheel mount and push on to frame as shown until it clicks into place.

PULL ON wheels to make sure both of them are securely attached.


3



Turn the stroller upside down, as shown, so the rear of the stroller is facing upwards.

To attach rear wheels, push wheel onto rear leg tube until it clicks into place. Repeat on other side.

Pull on wheels to make sure both of them are securely attached.





To remove, push metal button **©** and pull wheel off stroller.




To set up seat in toddler seat mode, flip toddler seat over and attach the buckles on the seat as shown.


5













Attach canopy by snapping it to both sides of the toddler seat as shown.

7



Fasten Velcro® at the top of seat as shown.



To attach bumper bar, push tabs openings on stroller. Make sure bumper bar locks into position with audible clicks.

**PULL ON** the bumper bar to make sure it is locked into place.

Child tray slot faces up



To remove the bumper bar, push both tabs **(1** and remove the bar from the stroller.








**WARNING**To avoid spills, remove child tray when reclining the toddler seat.


**To attach child tray,** insert the tab (1) on the tray into the slot on the armbar as shown.

To remove child tray, pull up and remove from the slot **①**.





**To attach cupholder,** slide down on the mount **①** on the side of the canopy as shown.



**WARNING** Always lock both brakes. Make sure brakes are on by trying to push the stroller.

To lock , press lever **DOWN** on both wheels as shown.



To unlock, lift lever **UP** on wheels as shown.








To extend canopy, pull it forward as shown.



To close, push canopy toward parent's handle as shown.







## **A WARNING**

To avoid serious injury, **DO NOT** raise or recline seat with child in stroller.

To recline seat, squeeze and slide down the adjuster **B**.


To raise the seat, hold the D-ring **()** on strap, then slide the adjuster toward the seat.

5



To avoid serious injury, **DO NOT** raise or recline seat with child in stroller.

**To recline toddler seat,** lift handle **①** at the top of the seat and rotate seat into one of 3 positions.




## USING YOUR STROLLER - SETTING UP STROLLER IN CARRIAGE MODE FROM TODDLER SEAT MODE

**WARNING NEVER** use seat in a reclined carriage position unless the straps under the seat are unbuckled and the seat is set up in reclined carriage mode as per the instructions.



If you are in Toddler Seat Mode as shown, follow these steps to convert to Carriage Mode.



Fully recline seat by squeezing button on the recline strap and lowering the backrest.




## **WARNING**To avoid spills, remove child tray


when reclining the toddler seat.

Lift handle up and rotate seat down.



## USING YOUR STROLLER - SETTING UP STROLLER IN CARRIAGE MODE FROM TODDLER SEAT MODE






CLICK!


11



5-pt Harness







## **WARNING**

To avoid serious injury from falling or sliding out, **ALWAYS** use waist restraint.

**Note:** Verify the stroller is locked in the open position by lifting up the rear of the stroller using the parent's handle.

Lock the rear brakes and remove the bumper bar (page 8).

#### 5-point Harness:

The harness shoulder straps **(6)** must be at shoulder height or lower, closest to the baby's shoulders **(1)**.

Place the baby in the seat and bring the crotch panel ① up between the child's legs. Fasten each buckle ①. For a snug, comfortable fit, pull the shoulder straps ⑥ to tighten the shoulder restraint and pull the waist restraint straps ⑥ to tighten the waist restraint.

#### Note:

To loosen the waist straps  $oldsymbol{\mathbb{G}}$ , push in the release button  $oldsymbol{\mathbb{G}}$  on the buckle and pull.

To loosen shoulder straps push up on the retainer  $\mathbf{0}$  while pulling down on the shoulder strap.


Once the child is properly restrained, re-attach the bumper bar. Make sure the bumper bar locks into position with audible clicks. Pull on the bumper bar to make sure it is locked into place.


#### **3-point Harness:**


#### To change from 5-point to 3-point harness:

Unlock the Harness: Depress button **(1)** as shown. Remove harness shoulder strap **(3)** from each buckle **(1)**, as shown.

Store shoulder harness straps for future use.







## **WARNING**


Care must be taken when folding or unfolding stroller to prevent finger injury in hinge areas.

**To fold the stroller**, adjust seat back to upright position, lock the rear brakes, close the canopy, and remove your child

Pull the levers **①** on both sides of the stroller and lower frame until the side frame lock **②** clicks into place.

For more compact fold, you can remove the toddler seat before folding the stroller frame.

NEVER fold the stroller when the toddler seat is in the carriage mode (p. 14).



Rotate handle down until the storage latch closes. You may need to push stroller together in order for the side frame lock to fully lock into place.



Double check storage latch **(P)** is securely closed.

In order for stroller to stand when folded, make sure the front wheels are facing forward.

15



To unfold the stroller, unlatch the side frame lock **①**. Continue holding the lock open while unfolding the stroller.

16



Grab the parent's handle and pull upward until the stroller opens fully with an audible click.


Make sure the stroller locks in the open

Make sure the stroller locks in the open position by pushing down on the parent's handle (see page 4).



## **A WARNING**

- Only use Evenflo SafeMax<sup>TM</sup> and LiteMax<sup>TM</sup> infant car seats with this stroller. Other infant car seats or carriers are not designed to fit the stroller frame and if used with this stroller may result in serious injury to your child.
- Before using the infant car seat with this stroller, read all the instructions provided with it and keep the instructions stored properly for future use.
- **DO NOT** lift stroller by using the infant car seat handle when installed on stroller.
- If unable to securely attach your infant car seat to this stroller, remove the car seat and contact Evenflo ParentLink at 1-800-233-5921 (USA), 1-937-773-3971 (Canada), or 01-800-706-12-00 (Mexico).
- To avoid serious injury, make sure the infant car seat is securely snapped onto the car seat mounts.
- Some **Evenflo SafeMax<sup>TM</sup> and LiteMax<sup>TM</sup>** infant car seats have a blanket/boot option that must be removed for proper attachment to this stroller.
- **1.** Remove toddler seat from the stroller frame if it is attached. (see pg. 11)
- 2. To attach infant car seat, line up circular hub (a) of handle with the seat mounts (b). Insert the car seat into the mounts until they click into place on both sides of the frame. LIFT UP on the car seat to make sure that it is securely attached.
- 3. The infant car seat MAY BE installed facing the parent or facing forward on the stroller frame.
- 4. Pull up on the front and back of the infant car seat to test that it is properly locked into place.



### **CHECKLIST FOR PROPER INSTALLATION**

- Make sure the infant car seat is securely locked into the car seat mounts.
- Pull up on the front and back of the infant car seat to test that it is properly locked into place.






**To remove the infant car seat**, pull the release handle **()** with one hand while lifting up on the carry handle **()** with the other hand.

## **A WARNING**

- Only use Evenflo SafeMax<sup>™</sup> and LiteMax<sup>™</sup> infant car seats with this stroller. Other infant car seats or carriers are not designed to fit the stroller frame and if used with this stroller may result in serious injury to your child.
- Before using the infant car seat with this stroller, read all the instructions provided with it and keep the instructions stored properly for future use.
- **DO NOT** lift stroller by using the infant car seat handle when installed on stroller.
- If unable to securely attach infant car seat to this stroller, remove the car seat and contact Evenflo ParentLink at 1-800-233-5921 (USA), 1-937-773-3971 (Canada), or 01-800-706-12-00 (Mexico).
- To avoid serious injury, make sure the infant car seat is securely snapped onto the car seat mounts.
- Some infant car seats have a blanket/boot option that must be removed for proper attachment to this stroller.
- To avoid injury, never use the infant carseat inside the toddler seat in the forward facing position.
- **NEVER** attach carseat to the toddler seat when the toddler seat is in the reclined position.
- **NEVER** use **Evenflo SafeMax<sup>TM</sup> or LiteMax<sup>TM</sup>** infant car seat or toddler seat in any other position other than what is recommended in these manufacturer's instructions.
- 1. Fully recline the seat back with the recline strap (pg. 12 Step 4). **NEVER** use the recline handle (pg. 12 Step 5) to recline the seat when installing the infant car seat into the toddler seat.
- 2. Make sure the bumper bar is securely latched (page 8).
- The infant car seat **MUST** be facing the parent when installed. Position infant car seat over the stroller. Touch rear vertical surface (a) of infant car seat against rear vertical surface (b) of bumper bar. Lower the infant car seat into the stroller and push down on handle until it clicks into the car seat mounts (b).
- 4. Pull up on the front and back of the infant car seat to test that it is properly locked into place.



#### **CHECKLIST FOR PROPER INSTALLATION**

Make sure the infant car seat is in the rear-facing position (facing the parent).

Make sure the infant car seat is securely locked into the car seat mounts 
and resting on the bumper bar 
.

Pull up on the front and back of the infant car seat to test that it is properly locked into place.





**To remove the infant car seat,** pull the release handle **①** with one hand while lifting up on the carry handle **④** with the other hand.

- Clean minor spills and stains on cloth or plastic surfaces with cold water and mild soap. Air dry.
- Metal and plastic parts can be wiped clean with a soft damp cloth and dried with a soft cloth. **DO NOT** use abrasive cleaners or solvents.
- An occasional drop of vegetable oil may reduce wear and tear on moving parts.

LIMITED WARRANTY

For a period of 90 days from the original purchase of this Product, Evenflo warrants to the original end user ("Purchaser") this Product (including any accessories) against defects in material or workmanship. Evenflo's sole obligation under this express limited warranty shall be, at Evenflo's option, to repair or replace any Product that is determined to be defective by Evenflo and determined to be covered by this warranty.

Repair or replacement as provided under this warranty is the exclusive remedy of the Purchaser. Proof of purchase in the form of a receipted invoice or bill of sale evidencing that the Product is within the warranty period must be presented to obtain warranty service. This express limited warranty is extended by Evenflo ONLY to the original Purchaser of the Product and is not assignable or transferable to subsequent purchasers or end users of the Product. For warranty service, contact Evenflo's ParentLink Consumer Resource Center at 1-800-233-5921 or www.evenflo.com.

EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS HEREBY DISCLAIMED. EVENFLO SHALL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL OR PUNITIVE DAMAGES OF ANY KIND FOR BREACH OF THE EXPRESS LIMITED WARRANTY ON THIS PRODUCT, OR ANY WARRANTY IMPLIED BY OPERATION OF LAW. OTHER THAN THE EXPRESS LIMITED WARRANTY SET FORTH ABOVE, THERE ARE NO OTHER WARRANTIES THAT ACCOMPANY THIS PRODUCT AND ANY ORAL, WRITTEN OR ANY OTHER EXPRESS REPRESENTATION OF ANY KIND IS HEREBY DISCLAIMED.

### ParentLink.

answers. advice. affirmation.™

- www.evenflo.com USA: 1-800-233-5921 8 AM 5 PM E.T.
  - Canada: 1-937-773-3971 México: 01-800-706-12-00